

Table of Contents

<i>Firmware License</i>	1
--------------------------------------	---

Firmware License

The firmware license is the license which is required for operation of each DHD core or DSP frame.

Usually, the cores will be delivered without a firmware license. This firmware license will be sent via e-mail.

After loading the firmware license into the device it is permanently stored in a separate flash memory. The firmware license will not be stored on the microSD card.



Note

An invalid license code allows unlimited operation of a device for 600 operating hours, this corresponds to 25 days non-stop operation. After that, the message `License invalid` is shown in the module display. Apart from this message, the mixer operation is still unlimited. After 800 hours of operation without license, the system is interrupted by a random reset approx. once per hour.

Page Title: Firmware License

Permanent link:

<https://support.dhd.audio/doku.php?id=licensing:firmware>

PDF Generated: 21.08.2020 | Last update: 2020/06/04 10:41