

Table of Contents

Licensing Overview	1
Search Topic	
Software Licenses and Feature Upgrade Licenses	
Firmware License	
See also	1



Licensing Overview

2	ar	rh	To	١ni	•
50	ui			יץי	·

Software Licenses and Feature Upgrade Firmware License Licenses

Software Licenses and Feature Upgrade Licenses Receive your Software License codes or Voucher Codes Load licenses into the device MicroSD Card Floating Licenses Enhanced DSP Processing License Licensing of the XC2 AES67 RAVENNA interface Firmware license code
Receive Firmware License Code
Load licenses into the device
Checking for Active Firmware License in the device

See also



Maintenance Window Documentation for entering Licenses.

DHDCS Documentation when having troubles connecting to your device.

Toolbox8 Documentation / Device Options for information on enabling licenses in your

Toolbox5 Documentation / Device Properties for older devices with firmware state 7.4 or less.

Page Title: Licensing Overview

configuration.

Permanent link:

https://support.dhd.audio/doku.php?id=licensing:start PDF Generated: 21.08.2020 | Last update: 2020/06/04 10:41