

Table of Contents

| | |
|----------------------------|----------|
| Project Setup | 1 |
|----------------------------|----------|

Project Setup

Configuring a DHD system is a complex process. There are always different ways to do it. The sequence of the individual steps is often not static. Despite this, the following list is to be understood as a proposal, how to configure for example a brand new 52/MX. This list is neither complete nor very detailed, but it gives a basic overview of the configuration process:

1. Set up the general options for the project. (see [Device Properties](#))
2. Insert a device: Right-click on the project tree and click `Add 52/XC` or `Add 52/XD`. (see [Project](#))
3. Select the hardware I/O modules for your setup and assign the correct APC ports. (see [I/O Overview](#))
4. Create your console layout: Select the fader and control modules for your configuration and assign the correct APC ports. (see [Console](#))
5. Set up the audio system with PGM busses, AUX busses, internal busses, fader channels etc. (see [Mixing Functions](#))
6. Set up the logic system to include key functions, GPIOs etc. (see [General Information on Logic](#))
7. Connect the audio signals and logic functions with output functions. (see [Output Functions](#))
8. Route the audio signals from the internal bus to the outputs of the hardware modules. (see [I/O Overview](#))

Page Title: Project Setup

Permanent link:

https://support.dhd.audio/doku.php?id=tb8:project_setup

PDF Generated: 14.07.2020 | Last update: 2020/06/04 10:41